6 Quick Keys to Achieve Density





6 Quick Keys

- 1. Temperature of the Mix
- 2. Consistent Mat Thickness
- 3. Limit Paver Stops
- 4. Trucking
- 5. Rollers
- 6. TAC (Time Available for Compaction)



